

### PREPARATION

**Note:** Important, refer to the "Service and Technical Booklet" included with the motorcycle.

Remove the front wheel.



Hex Key Wrench, 2mm  
Tools for removal and reinstallation of  
front wheel

### INSTALLATION

1. Remove the ABS ring from the left side of the wheel.
2. Insert the collar from the left side of the wheel into the right side Hub Cap. Thread a set screw into the hole in the Hub Cap.
3. Position the left Hub Cap in the center of the wheel. Reinstall the ABS ring.
4. Thread a set screw into the right Hub Cap.
5. Position the wheel between the forks.
6. Position the right Hub Cap in the center of the wheel.
7. Insert the axle from the right side, through the Hub Cap then the wheel and the Left Hub Cap and through the fork.
8. Complete the wheel installation per the instructions in the Service booklet.
9. Rotate the Hub Caps so the set screw hole points down.
10. Firmly tighten the set screw with the 2mm Hex Key Wrench.

### PARTS LIST

Hub Cap, Front, Left	1
Hub Cap, Front, Right	1
Set Screws	2

### MAINTENANCE AND CARE

The high quality chrome finish of your NationalCycle BMW® Hub Cap can be maintained with any quality chrome cleaner and/or polish.